



## APPLICATION INSTRUCTIONS

### SURFACE GUARD TAPE:

#### PREPARATION:

For best results, apply at temperatures between 50F-80F. Surface must be clean and free of dirt and/or wax prior to application. Use sharp scissors to cut Surface Guard to size before removing liner, experiment with a small piece first.

#### DRY APPLICATION:

Remove paper liner slowly as Surface Guard is applied. Squeegee into position very slowly. The slower the better. Again, experiment first.

#### WET APPLICATION:

Spray a mixed solution of soap and water on the surface to be applied over. Remove the liner, apply, position into place and squeegee out bubbles. Any bubbles can be punctured with a razor tip. Allow 24 hours to dry.

**Allstar Performance 8300 Lane Dr., Watervliet, MI 49098**

**Phone: (269) 463-8000 Fax: (800) 772-2618 [www.allstarperformance.com](http://www.allstarperformance.com)**