



# Locking Tear-Off Post Kit

## INSTALLATION

**Locking tear-off post kit features a set screw to keep the tension screw tight.**

1. Loosen locking set screw.
2. Install posts on shield; tighten post against shield to desired tension using Philips head screw.
3. Tighten locking set screw against Philips head screw to prevent post from loosening when adjusting to remove or install tear-offs.
4. Rotate posts with wrench flats.

**Allstar Performance 8300 Lane Dr., Watervliet, MI 49098**  
**Phone: (269) 463-8000 Fax: (800) 772-2618 [www.allstarperformance.com](http://www.allstarperformance.com)**