




## Backing Pad Kit Service Instructions

### WARNING!

1. Be sure pad is tightly secured to the spindle.
2. Always wear eye protection.
3. Do not exceed the maximum operating speed.
4. Always read your power tool operator's manual for additional instructions and safety information.

Install the backing pad onto the tool as shown below.

**NOTE:** Always install the rubber pad when using phenolic discs.



**Allstar Performance 8300 Lane Dr., Watervliet, MI 49098**  
**Phone: (269) 463-8000 Fax: (800) 772-2618 [www.allstarperformance.com](http://www.allstarperformance.com)**