



## Switch Panel

### INSTALLATION INSTRUCTIONS

#### **Allstar Performance Switch Panel Models 80140, 80141, 80142, 80160 and 80162**

- Connect the White wire from the ignition switch to a "+" positive battery connection, or the switched side of the battery disconnect switch.
- Connect the Red wire from the start button to the starter solenoid.
- Connect the Black wire from the ignition switch to the "+" positive side of the coil.
- ALL80142 loose indicator light wire must be grounded.

To protect wires on the switch panel from the elements, seal connections on the back of the panel with a good quality silicone.

**Allstar Performance 8300 Lane Dr., Watervliet, MI 49098**

**Phone: (269) 463-8000 Fax: (800) 772-2618 [www.allstarperformance.com](http://www.allstarperformance.com)**