




# Carbon Monoxide Filter

## ASSEMBLY AND USE

Unit includes two vacuum sealed filter bags (used one at a time, typically one per event) that must remain sealed until ready for use. Filter bags are non-returnable once removed from their vacuum sealed sleeve. Keeping filter bag in a sealed zip lock bag between race sessions will prolong effectiveness (6 hours max. once removed from vacuum sealed sleeve.) After 6 hours of exposure, discard filter bag and replace with a new one - even if a zip lock bag was used.

A freshly opened filter bag will be slightly saturated with a gel-like substance that can also be felt inside the bag. After six hours of exposure, the gel-like substance will have completely evaporated leaving only the dried foam agitators.



**Allstar Performance 8300 Lane Dr., Watervliet, MI 49098**  
**Phone: (269) 463-8000 Fax: (800) 772-2618 [www.allstarperformance.com](http://www.allstarperformance.com)**